

INSTRUCTION MANUAL

INDOOR AND OUTDOOR PROFESSIONAL REFRIGERATOR



Thank you for choosing this BLASTCOOL appliance. It is essential that you read these instructions carefully and keep the booklet in a safe place for your future reference. The booklet contains mandatory safety information as well as essential maintenance routines. Failure to observe the instructions is unsafe and will also invalidate the guarantee.



Caution! Risk of Fire



WARNING!

Any refrigeration repair or any electrical work must only be carried out by suitably qualified and competent persons.

TABLE OF CONTENTS

1. 0	SAFETY AND INSTALLATION	
1. 1	Safety Information.....	3-4
1. 2	Unpacking and positioning (before connecting to the power supply)...	4-5
1. 3	Connecting the appliance to the power supply.....	6
2. 0	OPERATION	
2. 1	Operation of the appliance.....	6
2. 2	Adjustment of the temperature.....	6
2. 3	Lighting controls.....	7
2. 4	Door heating controls (glass door models only).....	7
2. 5	Condenser fan speed control switch.....	7
2. 6	Eco mode.....	8
3. 0	MAINTENANCE	
3. 1	Lighting.....	8
3. 2	Cleaning the interior and exterior.....	8
3. 3	Cleaning the condenser.....	8
4. 0	IN THE EVENT OF A MALFUNCTION.....	9
5. 0	DISPOSAL AT END-OF-LIFE.....	9
6. 0	CONTACTS.....	9

The information within this booklet was correct at the time of printing.
Specifications and information may alter without notice.

1.0 SAFETY AND INSTALLATION

1.1 Safety Information



WARNING!

All electrical work must be carried out by suitably qualified persons



Warning! Please observe the following safety precautions and instructions at all times:

- This appliance is safety rated for outdoor use at IP24 conditions. These conditions are defined by BS EN 60529: 1992 as being that the appliance is protected against “splashing water” from any direction. Please note that it cannot be cleaned by the use of a water jet, nor can any part of it be immersed in water, for example by a temporary flood during a rainstorm.
- This appliance must only be connected to a power supply that has been installed by a qualified electrician. The type of connection to the power supply must be safe for outdoor use and it is recommended that a qualified electrician be consulted prior to outdoor operation.
- Do not use this appliance other than for its intended use as a professional refrigerator for food and beverages.
- Always disconnect the mains power supply before removing any covers, performing maintenance work, cleaning or making any repairs.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children.
- Do not cover the front grille or rear air vents and please observe the installation and setting up instructions described later in this manual. Adequate ventilation must be ensured for the appliance. Keep clear of obstruction all ventilation openings in the appliance enclosure .
- Do not probe any openings in the cabinet and be careful not to touch any moving parts such as the fans, or hot surfaces such as the compressor, or rear pipework; or cold surfaces such as the interior surfaces or the evaporator plate.
- Any electrical work on the cabinet should only be carried out by suitably qualified, competent and skilled persons.
- Do not overload the power supply. Always ensure that the power supply is sufficient for the electrical requirements specified on the rating label. The rating label is located inside the cabinet on the side wall. If in doubt, please consult a qualified electrician. Important: Never use adaptors or multi-block extension leads to connect the appliance to the mains power.
- If the mains power supply cord is damaged, it must be replaced by the appliance manufacturer, its service agent or suitably qualified, competent and skilled persons in order to avoid a hazard. A skilled person is somebody who possesses the appropriate technical training, experience and valid certifications necessary to be aware of the hazards to which he or she may be exposed and of the measures necessary to minimise the dangers to themselves and other persons.

- Do not store explosive substances such as aerosol cans with a flammable propellant inside this appliance.
- Do not use any electrical appliances inside the refrigerated compartment of this appliance.
- Do not use any mechanical devices or other means to accelerate the defrosting process. Defrosting is performed automatically by the electronic controller and needs no user intervention.
- Do not damage the refrigeration circuit. If you do so, then open a window or door immediately so as to ventilate the area. The refrigerant gas is highly inflammable, meaning that it can easily be ignited to explosive effect.
- This appliance contains flammable refrigerant within its sealed system and also within the insulation foam. As such it is mandatory that the cabinet is serviced and, at end-of-life, recycled by a professional organisation and skilled persons who have the necessary qualifications, certifications and expertise to do so. If in doubt please consult your Local Authority or contact Blastcool.
- The appliance uses LED lighting. The lighting strips and transformer should only be replaced using genuine Blastcool parts of the same technical specification.
- During all operations, please be careful not to jolt, jar, bump or thump the cabinet. Handle it gently and with care. The refrigeration pipework is delicate and will be damaged by rough handling.
- Do not exceed the maximum shelf loading weight of 15 kgs per shelf so as to avoid injury or damage.
- Never move or tilt the appliance whilst the power switch is in the “ON” position.
- The appliance must always be earthed.
- The appliance must only be charged with R600a refrigerant from an authorised supplier. To use another type of refrigerant would be dangerous and is not permitted under any circumstances.
- Electrical equipment should not be placed under the unit or where refrigerant could gather in the event of a leak.
- If it is necessary to open the refrigeration system during a repair, then it may be necessary for the technician to obtain a special Gas Work Authorisation. Queensland, Australia has particular regulations for such activities.
- The electrical wiring diagram is to be found on the appliance itself and is located on the right hand side wall.

1.2 Unpacking and positioning (before connecting to the power supply)

- Please read and observe all the warnings and procedures stated in section 1.1. These contain important safety advice concerning the safe positioning of the appliance.
- During all operations, please be careful not to jolt, jar, bump or thump the cabinet. Handle it gently and with care. The refrigeration pipework is delicate and will be damaged by rough handling.
- The appliance is heavy and therefore please carry out a risk assessment prior to beginning this operation.
- Please cut the banding straps taking the necessary precautions to avoid hurting yourself or others. Remove all of the packaging and ensure that it is recycled in

accordance with all local laws and regulations. Safety Note: Please pay special attention to the hazard represented by the plastic bag so that it may not be taken by children.

- Please take care not to pinch or damage the power cord in any way. Please examine the power cord for any splits, cuts or damage. If any are found do not under any circumstances connect to the power supply.
- Using a pair of scissors, please snip and remove the cable ties that are used to secure the shelves in transit.
- The shelves may be adjusted by moving the clips as illustrated in Figure 1 below:




Figure 1




Figure 2

- Warning: Do not exceed the maximum shelf loading weight of 15 kgs per shelf so as to avoid injury or damage. Please ensure that the shelf support clips are securely located in to the support strip for safe operations. The shelves may be adjusted by squeezing together the relevant support clips and re-locating in a new position. Please ensure the clips are fully inserted and securely located prior to loading the shelves. The clips should be mounted in such a way that the shelf is level. Please ensure that the shelf clips are securely located into the support strips. The shelves must be level so as to avoid a collapse.
- This appliance is officially rated to operate in Climate Class 5 Conditions (40 centigrade, 40% Relative Humidity).
- Do not place the appliance next to a source of heat or humidity. If this is the required arrangement, then suitable compartmentalisation must be arranged such that the heat from one appliance cannot cross-contaminate the cool air requirements of the other.
- Do not place the appliance in direct sunlight. The location should be shaded.
- Do not place near to a source of static electricity or where it is vulnerable to lightning strike.
- The room must be well ventilated and free from sources of ignition. It must not be located in a position where refrigerant could gather in the event of a leak. If it is below ground level then extra precautions may be necessary and an expert should be consulted.
- Please ensure that the appliance is placed on a level surface of sufficient strength to support the weight of the unit when filled to capacity. The levelling feet must be adjusted such that the appliance is perfectly level. This is necessary for the correct operation of the doors and the drainage system. Care must be exercised not to trap fingers when making the adjustments.
- The appliance requires a minimum ventilation space at the sides and top of 10mm. At the rear, 30-50mm is preferred, but 10mm is the minimum. See figure 2. The front grille must be completely unobstructed.

1.3 Connecting the cooler to the Power Supply

- Please observe all of the warnings and procedures stated in section 1.1.
- Please take care not to pinch or damage the power cord in any way. Please examine the power cord for any splits, cuts or damage. If it is unsatisfactory then it must be replaced according to the instructions stated in 1.1.
- Plug in the cooler and turn on the power.
- Switch on the appliance using the red power switch on the front control panel.



Power Switch


2.0 OPERATION

2.1 Operation of the appliance

- The appliance is designed to run automatically. Defrosting is automatic. The condensate water is evaporated automatically by the system.
- Maintenance must be performed according to the procedures detailed in section 3 of these instructions.

2.2 Adjustment of the temperature

- The appliance has been factory set to the chill the bottles to optimum serving temperature. To access the "SET POINT", simply press either of the UP or DOWN arrows on the controller display panel. To adjust the SET POINT, continue to press either the UP or DOWN arrows until the desired SET POINT is achieved. The selected SET POINT will be locked in and the display will revert to the current internal air temperature. Please note that in normal operation, the SET POINT denotes the coldest temperature the air will reach before shutting off or slowing down the compressor. The air temperature will be allowed to go approximately 4 degrees warmer before the refrigeration is requested to activate again. The temperature of the stored products may not have risen to the same extent as the air temperature.



2.3 Lighting controls



Light Switch

I = Blue lighting 0 = Off II = White lighting

- The colour of the lighting may be changed from white to blue using the “green” rocker switch, the middle position of switch is lighting OFF.


2.4 Door heating controls (glass door models only)




Door heater switch (glass door models only)

- The appliance is fitted with heated glass doors that are designed to assist in keeping the glass free of condensation in high humidity conditions. For energy saving purposes, it is recommended to leave the heaters switched off if no condensation is present. Some parts of the appliance may still be warm to the touch, even with the heater switch selected to OFF and this is perfectly normal.

2.5 Condenser fan speed control switch



Speed Switch



1-low speed,
0-high speed

- The speed of the condenser fan may be altered to reduce the noise level. In ambient temperatures of 30C or below, the low fan speed setting may be selected if noise is a concern. If you wish to alter the fan speed, you must first disconnect the appliance from the mains power supply and then remove the rear cover, taking care to observe all the safety precautions listed in section 1.1.

2.6 Eco Mode



The XP series of appliances incorporate some of the most energy efficient components currently available. However during periods of non-use, further energy savings may be achieved by selecting “Eco mode” unless food is being stored inside

- To select Eco mode, simply press and hold the Eco button on the controller until the display changes to “Eco”.
- The controller will temporarily alter the set point to 4C higher than the stored Set point selection. Caution: Not suitable for food storage.
- To return the cabinet to Normal mode, press and hold the “Eco” button until the display changes to “Nor”.

3.0 MAINTENANCE

Please observe all of the safety warnings, precautions and instructions set out in Section 1.


3.1 Lighting

- The appliance uses LED lighting strips powered by a low voltage transformer. If replacement is required, please order genuine replacement parts from BLASTCOOL. Replacement is a job for an appropriately qualified, skilled and competent person.

3.2 Cleaning the interior and exterior

- The interior should be cleaned and sanitised as often as necessary to ensure food hygiene. Never use an abrasive cleaning material or solution (such as cream cleansers) because they will damage the finish of the stainless steel. The exterior should be cleaned with water and household dish washing detergent, being careful to rub the surface in the same direction as the grain of the stainless steel. The glass should be cleaned using glass cleaning spray. Always observe the instructions of the cleaning solution being used. Caution: Do not use steam, jetting or running water to clean the appliance.

3.3 Cleaning the Condenser



① Use soft brush to sweep



② Use vacuum to remove debris

- The condenser is located at the rear of the appliance behind the compressor compartment cover. The function of the condenser is to dissipate the heat that has been extracted from the interior of the cabinet. In order for it to work efficiently, it must be kept clean and free of dust at all times.

- This appliance has a low maintenance condenser that is less prone to blockage than other types. However it is still recommended to check that it is clean and dust free at least every three months.

Step 1: Empty the appliance. Switch it off using the red power switch. Pull it out from its enclosure. Unplug from the mains power supply.

Step 2: Looking at the back of the appliance, remove the screws from the rear compartment cover.

Step 3: Locate the condenser and examine it for dust or debris.

Step 4: Clean the condenser using the nozzle of a vacuum cleaner or a soft brush. Dust that is removed must be cleared away. The condenser is a delicate component and must be treated with great care and respect. Be careful of the fan blades and be sure not to bend or deflect them in any way. NEVER use water in this area.

Note: If the condenser has been contaminated with grease or fat, then a skilled and competent refrigeration specialist will be required to do the cleaning. Do not use the cabinet or plug it back in until the cleaning has been done professionally by a skilled person. A fire hazard may be present.

Step 5: Replace the cover and screws and plug back in to the mains power supply.

4.0 IN THE EVENT OF A MALFUNCTION

- In the event of a malfunction, please be sure only to use a suitably qualified, competent and skilled refrigeration service engineer and insist upon genuine BLASTCOOL parts. If the appliance is under guarantee, please call the company from whom you purchased the appliance. Always have the serial number to hand. The serial number is located on the inside wall of the refrigerated compartment.

5.0 DISPOSAL AT END-OF-LIFE

- This appliance contains flammable refrigerant within its sealed system and also within the insulation foam. It must be recycled by a professional, competent, authorised and regulated organisation with expertise in the handling of refrigeration appliances. For further information, please consult your local Authority.



6.0 CONTACTS

- For further information or to obtain Genuine Spare Parts, please contact:

Staycold Export Ltd.

9 Hunters Walk

Canal Street

Chester

CH1 4EB

United Kingdom

Telephone from within UK:

01244 321320

Telephone from overseas:

+44 1244 321320

www.staycold.co.uk